

Shutter / blind actuator (RL module) RL 521/23
AC 230V, 2 x 6 A, with detection of end positions

5WG1521-4AB23

Product and functional description



The RL 521/23 shutter / blind actuator is a KNX device with two relay output channels. The device is installed in an AP 118 Control Module Box, an AP 641 room control box or an M 590 DIN rail housing. The bus is connected via a bus terminal block. The actuator electronics are supplied via the bus voltage.

The RL 521/23 may be used to control blinds, shutters, awnings, windows, or doors.

The device is designed to drive (per channel) one AC 230 V drive (motor) with electromechanical limit switches or with integrated electronics for disconnection at the limit positions.

For drives with electromechanical limit switches the actuator can be configured to detect the status of the electromechanical limit switches such that the travel time between the end positions can be measured via a synchronization run. The travel time of the blind / shutter is automatically measured from the upper end position to the lower end position and vice versa. The measurement is only reliable for drives with electromechanical limit switches. The travel time cannot be automatically adjusted for drives with integrated electronics for disconnection at the limit positions. These drives have to be controlled via a time limit. Their travel times have to be manually measured as precisely as possible and configured in the application program.

Parallel operation of several drives on one channel requires the intermediate switching of a special separation relay. If such a separation relay is connected to the output to drive several drives in parallel, then the travel time has to be configured manually.

If the device is configured for automatic detection of the travel time, then parallel operation of several drives with electromechanical limit switches or mixed operation with drives with integrated electronics for disconnection at the limit positions is not permitted.

Detection of final positions, Automatic detection of travel times

The device can detect if the blind / shutter is in the upper or lower end position. This detection depends on the solar protection drive (motor) itself and on the wiring and specifically cannot be guaranteed for drives with integrated electronics for disconnection at the limit positions. Hence, the detection can be disabled by a parameter. If automatic detection of end positions is enabled, the travel time is set to the maximum value after a download of the configuration. If the end positions were detected successfully and the solar protection moved without interruption from the lower position to the upper position, then the parameter value for the travel time is updated and saved. The same applies to the travel time from the upper to the lower end position.

When the end position is detected, then the parameter value for the travel time extension is set to 10% of the travel time. In principal, the travel time, i.e. the time the relay contacts are closed, is determined based on the configured value or the parameter value updated based on the travel times measured between end positions

After a download of the application program respectively of addresses and parameters the solar protection must be synchronized. This is triggered when a telegram "solar protection up/down" or "central up/down" is received. The solar protection then performs a synchronization run. First it briefly moves down, then fully into the upper end position. Then it moves from the upper end position to the lower end position measuring the associated travel time. Finally, it moves from the lower end position to the upper end position measuring the associated travel time. After this procedure the solar protection is synchronized and remains in the upper end position until a motion is triggered by another telegram.

If the actuator does not detect the upper end position at the start of the synchronization run, then the measurement travels are not executed. In that case, the actuator is not synchronized. The synchronization run has to be initiated again as described above.

Any additional telegram "solar protection up/down" or "central up/down" received during the synchronization run is ignored. If a telegram "slats open/close" is received this is interpreted as stop and the solar protection is stopped without finalizing the synchronization of the actuator. The synchronization run has to be initiated again as described above.

Shutter / blind actuator (RL module) RL 521/23
AC 230V, 2 x 6 A, with detection of end positions

5WG1521-4AB23

If a message "block motion" is received during the synchronization run, then the synchronization run is aborted. It can only be initiated again, when the motion blockage is ended by a respective telegram.

All other telegrams received after a download before and during a synchronization run are ignored.

If the solar protection shall move to the upper or lower end position in normal operation, the travel time is calculated such that the drive reaches the respective end position. The actuator stops the motion when the end position is detected. A possible short opening movement of the slats or a short lifting of a roller shade is immediately executed after stopping the motion.

When a change of the solar protection travel times of more than $\pm 5\%$ is detected during normal operation based on the end position detection, then the travel time configuration settings are corrected and saved accordingly.

Because the electromechanical end position switch does not close at the same time the solar protection leaves the end position, it is necessary to block evaluation of the end position for this period. This "blocking period" can be configured via a parameter. Typical values for the blocking period are 0.5 to 1.0 seconds.

Behavior at bus voltage failure / recovery

In the event of bus voltage failure the current positions of solar protection and slats as well as the travel time configuration is permanently saved to be restored on bus voltage recovery. Object values are not saved.

Status objects are not read after a bus reset.

Actions configured for execution on bus voltage failure are only executed, if no alarm or blockage is active.

Actions configured for execution on bus voltage recovery are only executed and possible new positions transmitted, if no alarm or blockage was active before bus voltage failure. The information (not the object values) about alarm and blockage before bus voltage failure is only saved for the initialization phase after bus voltage recovery. It is reset (no alarm active, no blockage active) after initialization. Consequently, if e.g. before bus voltage failure a blockage was active, the solar protection cannot be moved into a configured position on bus voltage failure or on bus voltage recovery. If after bus voltage recovery further messages to move the solar protection are received, then these are executed because the blockage present before bus voltage failure is not saved. Thus an explicit release of a blockage after bus voltage recovery is not required.

If alarm surveillance periods are configured, then these are restarted on bus voltage recovery.

The synchronization is retained on bus voltage failure and recovery. Yet, the actuator assumes that any function configured for bus voltage failure has been fully executed. If this is not the case, the calculated position may deviate from the actual position until the solar protection has been moved to an end position.

Behavior on unloading the application program

When the application program is unloaded with ETS the device does not function.

Resetting the device to ex-factory settings

When the programming button is pressed for more than 20 seconds the device is reset to the ex-factory settings. All configuration settings are lost.

The device is configured and commissioned with the ETS (Engineering Tool Software) version ETS3 v3.0f or later.

Application Program

The RL 521/23 **Shutter / blind actuator** needs the application program "07 B0 A1 Shutter Actuator 982B01".


Shutter / blind actuator (RL module) RL 521/23
AC 230V, 2 x 6 A, with detection of end positions
5WG1521-4AB23**Example of operation**

figure 1. Example of operation

Installation notes

- The device is intended for installation in an AP 118 Control Module Box, an AP 641 Room Control Box or an M 590 DIN rail housing.

**DANGER**

- The device must be mounted and commissioned by an authorized electrician.
- A safety disconnection of the device must be possible.
- The device must not be opened.
- For planning and construction of electric installations, the relevant guidelines, regulations and standards of the respective country are to be considered.
- **When looping through the L-conductor, take care that the maximum permissible terminal load current of 16 A is not exceeded!**


Location / Function of the Display and Operating Elements

figure 2: Location / Function of the Display and Operating Elements

- A1 LED for indicating normal operating mode (LED off) or addressing mode (LED on); returns to normal operating mode automatically after receiving the physical address
- A2 Learning button for switching between normal operating mode and addressing mode and for receiving the physical address
- A3 Bus connection pins of the module for connection of the bus terminal block for single core conductors with 0,6...0,8 mm Ø
- A4 Type label (with space for physical address of the actuator)
- A5 Terminal Channel A, down
- A6 Terminal Channel A, up
- A7 Terminal L
- A8 Terminal Channel B, down
- A9 Terminal Channel B, up
- A10 Terminal N
- A11 Identification number of the device

Shutter / blind actuator (RL module) RL 521/23
AC 230V, 2 x 6 A, with detection of end positions

5WG1521-4AB23

Technical Specifications

Power supply

- via the bus line
- KNX bus voltage:
DC 24 V (DC 21...30 V) via KNX/EIB bus line
- KNX bus current: < 10 mA

Outputs

- Mains connection:
carried out via the terminals for L and N of the actuator
- 2 drive channels each with 2 relay contact outputs,
 - rated voltage: AC 230 V, 50/60 Hz
- rated current: 6A (resistive load)
- switching current at AC 230 V:
 - 0,01 ... 6 A resistive load
 - tubular motors with auxiliary phase capacitor
≤ 14 µF, max. power 500 VA at 20000 load
switching cycles (UP-DOWN-STOP) respectively
max. 750 VA at 12000 load switching cycles
 - total maximum load at $\cos\varphi = 0,4$; 750 VA
- switching current at DC 24 V:
 - 6 A resistive load,
 - 4 A inductive load (L/R = 7 ms)

Control elements

1 learning button:
for switching between normal operating mode and
addressing mode

Display elements

1 red LED:
for monitoring bus voltage and for displaying normal
mode/addressing mode

Connections

- Bus line : Bus connection pins for connection of the
screwless bus terminal block (red-black) 0.6...0.8 mm
Ø single core, strip insulation 5mm
- Load circuit: screwless terminals
0.5 ... 2.5 mm² single-core, stranded or multi-core,
untreated, strip insulation 9 ... 10 mm
- The device must be fused with a miniature circuit
breaker of characteristic B or C with a max. nominal
current of 16 A.

Physical specifications

- housing: plastic
- dimensions (L x W x D): 86,5 x 47,8 x 36,2 mm
- weight: approx 70 g
- fire load: approx. 1400 kJ
- Installation: Mounting location for RS / RL module in
AP 118 Control Module Box (5WG1118-4AB01), AP 641
Room Control Box (5WG1641-3AB01) or M590 DIN rail
housing (5WG1590-8AB01).
- Thermal dissipation loss:
Device: 0,15 W (= min. total thermal dissipation loss)
per output: on-time[%] * (1W + 0,033 * I²) [W]
min. total thermal dissipation loss: 0,15 W (load: 0 A)
max. total thermal dissipation loss: 4,53 W (load: 2 * 6
A, 100%)

Electrical safety

- Degree of pollution (according to IEC 60664-1): 2
- Type of protection (according to EN 60529): IP 20
- Overvoltage category (according to IEC 60664-1): III
- Bus: safety extra low voltage SELV DC 24 V
- Device complies with: EN 50428

Electromagnetic compatibility

complies with EN 50428

Environmental conditions

- Climatic conditions: EN 50090-2-2
- Ambient operating temperature: - 5 ... + 45 °C
- Storage temperature: - 25 ... + 70 °C
- Relative humidity (not condensing): 5 % ... 93 %

Reliability

- Failure rate: 1068 fit at 40 °C

Markings

KNX, EIB

CE norm

- complies with the EMC regulations (residential and
functional buildings),
low voltage regulations

Shutter / blind actuator (RL module) RL 521/23
AC 230V, 2 x 6 A, with detection of end positions

5WG1521-4AB23

Installation and wiring

- B2 RL module
- B3 Type label
- B4 Mounting location for RS / RL module in AP 118 Control Module Box (5WG1118-4AB01), in AP 641 Room Control Box (5WG1641-3AB01)
- B8 Learning button
- B9 LED for indicating normal operating or addressing mode
- B10 Bus connection pins for connection of the bus terminal block
- B11 Insertion point for bus terminal block
- B12 Bus terminal block
- B13 Hinge joint for mounting hinge of the RL module
- B14 Terminals

- Mounting of an RL module :
 - Remove the lid of the AP 118 Control Module Box respectively of the AP 641 Room Control Box.
 - AP 641: Remove the SELV (Class 2) cover
 - Insert the RL module (B2) into the hinge (B13) of the mounting location (B4). The terminals (B14) point away from the insertion point for the bus terminal (B11). The type label (B3) is on top.
 - Swivel the RL module (B2) down until it audibly snaps into the mounting location (B4).
 - Insert the bus terminal (B12) of the mounting location (B4) onto the bus connection pins (B10) of the RL module (B2).
 - For assignment of the Physical Address press the learning button (B8) for a maximum of 2 seconds. The addressing mode is indicated when the LED is on (B9). It returns to normal operating mode (LED Off) automatically after receiving the physical address.
 - AP 641: Insert the SELV (Class 2) cover again.
 - Mount the lid again.




figure 3: Mounting of an RL module

Shutter / blind actuator (RL module) RL 521/23
AC 230V, 2 x 6 A, with detection of end positions

5WG1521-4AB23

- Dismounting an RL module :
 - Remove the lid of the AP 118 Control Module Box respectively of the AP 641 Room Control Box.
 - AP 641: Remove the SELV (Class 2) cover
 - Remove the wiring from the terminals (B14).
 - Remove the bus terminal (B12).
 - To remove the RL module (B2), insert a screw driver between the module and the mounting location on the bus terminal side and push it up to release it from the snap-in hooks.
 - Swivel the RL module (B2) up, pull it down out of the hinge (B13) and remove it from the mounting location (B4).
 - AP 641: Insert the SELV (Class 2) cover again.
 - Mount the lid again.




figure 4: Dismounting an RL module

Connecting

Slipping off/on bus connection blocks

It consists of two components (C2.1 and C2.2) with four terminal contacts each. Take care not to damage the two test sockets (C2.3) by accidentally connecting them to the bus cable or with the screw driver (e.g. when attempting to unplug the bus connection block).

Slipping off bus connection blocks

- Carefully put the screw driver to the wire insertion slit of the bus connection block's grey component (C2.2) and
- pull the bus connection block (C2) from the module (C1).

Note

Don't try to remove the bus connection block from the bottom side. There is a risk of shorting-out the device!

Slipping on bus connection blocks

- Slip the bus connection block (C2) onto the guide slot of the module (C1) and
- press the bus connection block (C2) down to the stop.




figure 5: Slipping off/on bus connection blocks

Shutter / blind actuator (RL module) RL 521/23
AC 230V, 2 x 6 A, with detection of end positions

5WG1521-4AB23

Connecting bus cables

- The bus connection block (D2) can be used with single core conductors $\varnothing 0.6...0.8$ mm.
- Remove approx. 5 mm of insulation from the conductor (D1) and plug it into the bus connection block (D2) (red = +, grey = -)

Disconnecting bus cables

- Unplug the bus connection block (D1) and remove the bus cable conductor (D2) while simultaneously wiggling it.




figure 6: Connecting / Disconnecting bus cables

Connecting/disconnecting mains and load circuit:

Connect wires

- The load circuits are connected via screwless plug-in terminals (E1).
- Remove approx. 9...10 mm of insulation from the wire (E 1.1) and plug it into the terminal (E1).
- The terminals are designed for connection of two wires allowing to loop through the terminal block.

Note:

The maximum permissible terminal load current is 16 A.

Remove wires

- Press the terminal interlocking of the terminal (F1) with a screw-driver and remove the wire (F2) from the terminal (F1).





figure 7: Connecting / Disconnecting mains and load circuit

Dimension drawing

Dimensions in mm



General Notes

- The operating instructions must be handed over to the client.
- Any defective device should be sent the local Siemens office.
- If you have further questions concerning the product, please contact our technical support:
 ☎ +49 89 9221-8000
www.siemens.com/supportrequest

Shutter / blind actuator (RL module) RL 521/23 AC 230V, 2 x 6 A, with detection of end positions	5WG1521-4AB23
---	---------------

Space for notes